

child safety is nothing to play around with

We care about your kids. And pets, too. So when it comes to safety, we take our role seriously. We offer a wide range of cordless products and other features to help reduce the risks of accidents. And we encourage you to assess all windows in your home for potential risks.



CORDLESS CHOICES




Press a button on the bottomrail handle to lift and lower the shade. Release the button to securely lock the shade into place.



A light push or pull lifts or lowers shade to any desired position. There are no exposed cords.



Automation options eliminate operating cords and provide convenience for all windows, including those that are hard to reach. Raise and lower shades with the touch of a button, tap on an app or sound of your voice.



Vertically oriented shade opens from side-to-side, making it a perfect option for sliding glass doors and large windows.



Moves the blinds/shades side-to-side across the window with a sturdy wand.



By design shutters are cordless, eliminating potential safety hazards posed by operating cords.

OTHER SAFETY OPTIONS



Retractable pull-cord remains a constant length whether the shade is raised or lowered.



Combination design integrates both tilt and traverse functions into one easy-to-use control that keeps the cord taut.



Many of our child-safe options are Certified Best for Kids. Look for the logo when safety is a priority.

SAFETY REFERENCE CHART

	CORDLESS CHOICES						
	Cordless Lift & Lock	Cordless Lift	PowerWand	Automation	Vertical App	Wand Control	No Cords by Design
Aluminum Blinds	•					•	
Dual Shades			•	•			
Faux Wood Blinds	•	•		•		•	
Honeycomb/Cellular Shades	•	•	•	•	•		
2" Hybrid Shades	•	•		•	•		
Natural Woven Shades		•		•			
Natural Woven Panel Track						•	
Roller Shades		•	•	•			
Roller Panel Track						•	
Shutters							•
Vertical Blinds						•	
Vertical Shadings						•	
Window Shadings		•	•	•			
Wood Blinds	•	•		•		•	

EVERYONE IS RESPONSIBLE FOR CHILD SAFETY

AWARENESS IS THE FIRST STEP IN PREVENTION

Assess all windows in your home and pay attention to:

- Position cribs, beds, playpens and other furniture away from walls with windows and window treatments.
- Check your current window treatments for exposed or dangling cords. To order a FREE retrofit kit for older window treatments, contact the Window Coverings Safety Council directly:
1-800-506-4636
info@windowcoverings.org
www.windowcoverings.org
- Keep cords out of reach of children.
- Eliminate any dangling cords with cordless window treatments.
- Permanently anchor continuous cord loop window covering cords to the floor or wall.

WARNING NOTIFICATIONS

The window coverings industry uses warning tags, labels and other methods to communicate the potential hazard of corded window coverings. Pay attention to these warnings.

For example, the warning shown here communicates the critical message about cords being a potential strangulation hazard and suggests selecting a cordless alternative. Along with the Window Covering Safety Council, we strongly encourage you to install only cordless window coverings in homes where children play and sleep.

WARNING/ADVERTENCIA

Window Blind Cord Can **STRANGLE** Your Child. To prevent strangulation, purchase cordless products or products with inaccessible cords.

La cuerda de la persiana puede **ESTRANGULAR** a su niño. Para evitar el estrangulamiento, compre alternativas cuerda o productos con cuerdas inaccesibles.