



App Overview and Basic Navigation

HOME



- 1 Main Menu
- 2 Locations
 Up to 5 locations per account
 Up to 5 hubs per location
- All Rooms
 Up to 30 per location
- 4 All shades and blinds
 Up to 30 per location
- All paired shades or created rooms
- 6 Adding shades/creating rooms
- 7 Home Screen
- 8 Frequently used shades and scenes
- 9 Scenes
 Up to 20 per hub
- 10 Timers
 Up to 20 per hub

INDIVIDUAL SHADE




11 Power Level

Battery

- Green = Full
 - Solid Green = Powered
- Yellow = Medium
- Greyed out = Offline
- Red = Low
- Empty = Dead
- Greyed out = Offline
- 12 Shade's settings and programming
- 13 Strength of signal from hub to shade
 - Excellent
- Average
- Good
- Poor
- Shade animation.Drag with finger to desired height.
- 15 Shade's current % of openness.
 - 100% = Fully raised
 - 50% = Halfway
 - 0% = Fully lowered
- 16 Optional control buttons.

SCENES



Find yourself constantly adjusting the shades in your office to account for the glare of the sun in the afternoon? Create a scene for the preferred heights for each shade and just press "Go".

Programming Scenes:

Programming a scene is accomplished by either method outlined below.


- Update Scene Devices: Selecting the desired position of each shade based on the % of openness.
- Capture All Devices: Capture the current position of all shades and set that is your scene.

Scene Timers:

Take the experience a step further by associating that scene with a timer. This way you don't even have to worry about hitting the "Go" button.

Up to 20 Scenes per hub

TIMERS



Have your shades automatically adjust themselves to your desired heights based on the time of day and preferred day of the week.

Programming Timers:

• Scene or Device: Select whether you want to create a timer for a programmed scene or with a specific device (shade).

Once you have selected Scene or Timer, select whether you want to program that timer for a specific time or base it on your local sunrise or sunset time.

- Specific Time: Select the time that you want your shade or scene to operate.
- Sunrise/Sunset: Select whether you
 want your shades to operate at exactly
 the local sunrise or sunset time or
 choose to have them operate at a
 defined amount of time before or after.

Up to 20 Timers per hub





